


iBuyGrillParts.com

SBH200-1

## PARTS LIST

Index No.	Part Number	Description	Qty.
1	SB-141601/414	Manual Valve Botton	4
2	SB-141606/402	Panel	1
3	GB818-85	Screw M6 x 12	4
4	GB818-85	Screw M4 x 12	4
5	SB-141601/1900	Gas Valve Accessory	1
6	SB-141606/408	Left Panel Rack	1
7	GB818-85	Screw M4 x 12	2
8	SB-141601/404	Thermal Insulation Sheet	1
9	SB-141601/413	Ignitor Needle	2
10	SB-141601/1801	Drip Pan	1
11	SB-141601/410	Oil Dish	1
12	SB-141601/1700	Oven Body	1
13	SB-141601/407	Ignitor Box	2
14	SB-141601/405	Left Gemel	1
15	SB-141907/1011	Side Light Leader	2
16	SB-141601/406	Right Gemel	1
17	SB-141907/1012	Middle Light Leader	1
18	SB-141606/400	Burner	4
19	SB-141604/130	Heat Tents	2
20	SB-141601/412	Cooking Grid	2
21	SB-141601/409	Right Panel Rack	1
22	SB-141601/415	Ignitor	1
23	SB-141801/1006	Knob Base	4
24	SB-141606/236	Oil Retainer	1
25	SB-141605/6000	Base Cart	1

## HOOD VIEW




## PARTS LIST

Index No.	Part Number	Description	Qty.
1	GB819-85	Screw M6 x 15	10
2	SB-141601/305	Left Cover	1
3	SB-141601/304	Cover Handle	1
4	SB-141601/303	Warming Rack	1
5	SB-141601/301	Right Cover	1
6	GB93-87	Wash 6	10
7	GB95-85	Electric Wash	10
8	GB41-86	Nut M6	10
9	SB-141601/302	Cover	1
10	SB-141601-306	Thermometer	1
11	SB-141903/3113	Thermometer Base	1
12	SB-141601-307	Handle Stock	1

SBH200-1

SBH200-1  
Hood View


## LEFT SIDE SHELF VIEW



### PARTS LIST

Index No.	Part Number	Description	Qty.
1	SB-141601/101	Push Handle	1
2	SB-141601/501	Left Bedplate	1
3	SB-141601/600	Table Frame	1
4	GB818-85	Screw M6 x 12	3
5	SB-141601/700	Cruet Accessory	1
6	GB41-86	Nut M6	2
7	GB5780-86	Bolt M6 x 62	2

## RIGHT SIDE SHELF VIEW



### PARTS LIST

Index No.	Part Number	Description	Qty.
1	SB-141601/101	Push Handle	1
2	SB-141606/102	Right Bedplate	1
3	SB-141601/600	Table Frame	1
4	GB818-85	Screw M6 x 12	3
5	SB-141601/700	Cruet Accessory	1
6	GB41-86	Nut M6	2
7	GB5780-86	Bolt M6 x 62	2

**SBH200-1  
Shelves**