



©IBS  
888-634-4289

1	30005708K	FRONT LID ASSEMBLY	1
2	30005707	VC LOGO ASSEMBLY	1
3	20300394	TEMPERATURE GAUGE	1
4	20300395	BEZEL FOR TEMPERATURE GAUGE	1
5	50004404	CURVED HANDLE GRIP SET	1
6	50000355	HARDWARE LID SET	1
7	50000365	LID BUMPER SET (6)	1
8	30005711K	REAR LID ASSEMBLY	1
9	30005837	WARMING RACK	1
10	30005363	COOK GRATES	3
11	20304959	HEAT PLATE	4
12	30005772	GREASE TRAY	1
13	50001845	GREASE CUP	1
14	50004258	GREASE CUP HOLDER	1
15	91D0132	BURNER MAIN ANGLE ASSEMBLY - INCL. ELECTRODE AND WIRE	4
16a	20302816	VALVE MANIFOLD ASSEMBLY - LP	1
16b	20302817	VALVE MANIFOLD ASSEMBLY - NG	1
17a	20300847	ORIFICE SEAR BURNER - LP opt.	1
17b	20300766	ORIFICE SEAR BURNER - NG opt.	1
18a	50004143	TUBE AND ORIFICE ASSEMBLY - LP	1
18b	50004144	TUBE AND ORIFICE ASSEMBLY - NG	1
19	91D0108	ELECTRODE WIRE MAIN LONG - NEED 91D0107 FOR ELECTRODE	4
20	91D0107	ELECTRODE ONLY - MAIN	4
21	50000892	BURNER GASKET	4
22	50000879	FLASH TUBE	1
23	30005717K	CONSOLE w/RIVNUT ASSEMBLY	1
24	50002788	IGNITOR PUSHBUTTON	1
25	50002533	IGNITOR PLATE	1
26	50001819	IGNITOR MODULE 6 POLE	1
27	30006393	BEZEL ASSEMBLY - BACKLIT	5
28	50003984	KNOB	5
29	50003110	BATTERY CASE - BACKLIT KNOBS	1

©IBS  
888-634-4289

30	50001668	WIRE CONNECTOR 33in	1
31	91D0134	ROTISSERIE KIT - w/o spit rod	1
32	91D0131	ROTISSERIE MOTOR	1
33	50004840	ROTISSERIE FORK KIT	1
34	50000399	SPIT ROD SUPPORT BRACKET	1
35	50003500	ROTISSERIE BURNER ASSEMBLY	1
36	50003472	ROTISSERIE ELECTRODE	1
37	50004275	ROTISSERIE MOTOR BRACKET	1
38	20300398	SPIT ROD - 29IN.	1
39	30005427	SPIT ROD STORAGE BRACKET	2
40	50004266	WIRE HARNESS	1
41	50003473	ROTISSERIE ELECTRODE WIRE	1
42	91D0111	HOSE REGULATOR - LP	1
43	91D0112	CONNECTOR HOSE - NG	1
44	20302809	HOSE PLUG - SIDE BURNER	1
45	50002384	NATURAL GAS HOSE - 12FT	1
48	50002914	SNAP BUSHING 3IN	2
49	30005410	LEFT SHELF ASSEMBLY	1
50	30006873	RIGHT SHELF ASSEMBLY	1
51	91D0140	HARDWARE BAG SIDE SHELVES	1
52	91D0136	CONDIMENT TRAY LEFT	1
53	91D0137	CONDIMENT TRAY RIGHT	1
54	50004320	TOWEL BAR	2
55	50004417	UTENSIL HOOK	3
56a	30005679K	SIDE BURNER ASSEMBLY - LP	1
56b	30005453K	SIDE BURNER ASSEMBLY - NG	1
57	30005470K	SIDE BURNER COVER	1
58	50001044	SIDE BURNER - BURNER ONLY	1
59	50001034	SIDE BURNER GRATE	1
60	20300400	VC LIGHT KIT	1
61	50002033	MAGNET SNAP IN	4
62	30005723K	DOOR ASSEMBLY SS - LEFT/RIGHT	2
63	50004204	DOOR HANDLE CURVED -128mm	2
64	50004255	CASTER 3 IN	3
65	50004256	CASTER 3IN W/BRAKE	1
66	91D0155	HARDWARE BAG CASTERS	1
68	50004650	TANK PULL OUT ASSEMBLY - LP ONLY	1
N/S	20300399K	CORNER POST	4
N/S	30006061	VC GRILL COVER - BAGGED	1
N/S	30006824	USER MANUAL	1
N/S	30006825	ASSEMBLY MANUAL	1
N/S	30006826	PARTS LIST	1

©IBS

888-634-4289

©IBS

888-634-4289