



©IBS  
888-634-4289

1	91D0132	MAIN BURNER ASSEMBLY - c/w ELECTRODE & WIRE	5
2	50000892	BURNER GASKET	5
3	50001300K	FLASH TUBE	2
5	30005408K	CONSOLE w/RIVNUT ASSEMBLY	1
6	50002788	IGNITOR PUSHBUTTON	
7	50002533	IGNITOR PLATE	
8	50004221	IGNITOR MODULE ASSEMBLY	
9	91D0111	HOSE REGULATOR - LP	
10	50003002	BEZEL ASSEMBLY - BACKLIT	
11	50003984	KNOB	
12	50004324	WIRE HARNESS	
13	20300400	VC LIGHT KIT	
14	91D0136	CONDIMENT TRAY LEFT	
15	91D0137	CONDIMENT TRAY RIGHT	
16	30005448	SMOKER BOX KIT	
17	20300520K	ACCESSORY SHELF	
18a	20304492	LEFT SHELF KIT - LP	
18b	20204492	LEFT SHELF KIT - NG	
19a	20304487	RIGHT SHELF KIT - LP	
20	20304683	RIGHT SHELF KIT - NG	
21	50004320	TOWEL BAR	
22	50003473	ROTISSERIE ELECTRODE WIRE	
23c	20304959	HEAT PLATE	
23d	50004145	TUBE & ORIFICE ASSEMBLY 1.15MM - LP	
24	50004146	TUBE & ORIFICE ASSEMBLY NO.51 - LP	
25	50003462	ROTISSERIE BURNER ASSEMBLY	
26	30005363	COOK GRATES	
27	20300413	DOOR UPPER BRACE	
28	50002033	MAGNET SNAP IN	
29	50001845	GREASE CUP	
30	20300395	BEZEL FOR TEMPERATURE GAUGE	
32	30005685	BACK PANEL - BLACK	
33	50002490	SNAP BUSHING 2IN	

©IBS

888-634-4289

©IBS

888-634-4289

34	30005692K	DOOR ASSEMBLY - SS
35	50004204	DOOR HANDLE CURVED -128mm
36	30005687	SIDE PANEL RIGHT
37a	30005688	SIDE PANEL LEFT
37b	30005469	SIDE BURNER COVER
38	30005679	SIDE BURNER ASSEMBLY - LP
39a	30005453	SIDE BURNER ASSEMBLY - NG
39b	50001035	SIDE BURNER GRATE
40	50001046	VALVE SIDE BURNER - LP
41	50001045	VALVE SIDE BURNER - NG
42	30005409K	GREASE PAN
43	30005396K	REAR LID ASSEMBLY
44	30005342	WARMING RACK
45	30005387K	FRONT LID ASSEMBLY
46	30000355	HARDWARE LID SET
47	50000365	LID BUMPER SET (6)
48	30005626	LOGO ASSEMBLY
49	20300394	TEMPERATURE GAUGE
50	91D0108	ELECTRODE WIRE
51	91D0107	ELECTRODE ONLY - MAIN
52	50000113	SIDE BURNER KNOB
53	50001044	SIDE BURNER - BURNER ONLY
54	91D0112	CONNECTOR HOSE - NG
55	50002384	12 FOOT HOSE - NG
56	91D0134	ROTISSERIE KIT - w/o spit rod
57	30005426	BATTERY SHROUD ASSEMBLY
58	91D0131	ROTISSERIE MOTOR
59	50004404	CURVED HANDLE GRIP SET
60	20302809	HOSE PLUG - SIDE BURNER
61	50004255	CASTER 3IN
62	50004256	CASTER 3IN W/BRAKE
63	50003472	ROTISSERIE ELECTRODE
64	91D0140	HARDWARE BAG SIDE SHELF
65	20300623	HINGE 20 GA. 20.5IN. - SS
66	20300417	SPIT ROD - 29IN.
67	50002888	CYLINDER RETAINER - LP
68	91D0155	HARDWARE BAG CASTERS
69	50004258	GREASE CUP HOLDER
70	50004417	UTENSIL HOOK
70a	30005427	STORAGE BRACKET SPIT ROD
71	20302818	VALVE MANIFOLD ASSEMBLY - LP
72	50004142	VALVE MANIFOLD ASSEMBLY - NG
73	50000399	SPIT ROD SUPPORT BRACKET
74	50004275	ROTISSERIE MOTOR BRACKET
75	50003110	BATTERY CASE - BACKLIT KNOBS
76	50002914	SNAP BUSHING 3IN
77	50004840	ROTISSERIE FORK KIT
78	30005689	CORNER POST
79	30005425	BOTTOM PANEL BLACK
N/S	30005888	SUPPORT CORNER
N/S	30005727	USER MANUAL
N/S	30005729	ASSEMBLY MANUAL
N/S	30005728	PARTS LIST
N/S	30005458	VC GRILL COVER - BAGGED

©IBS

888-634-4289

©IBS

888-634-4289